

Reinstall DELL Drivers on DELL Basic PC

You received a Operating System disc and a Drivers & Utilities disc with your DELL PC.

1. Turn the computer on and when you get to the desktop insert *the DELL Drivers and Utilities* disc.
2. On the *Resource CD Installation* pop-up click **OK**.
3. A wizard will begin to install the CD.
4. Click **Next**.
5. Click **Install**.
6. Click **Finish**.
7. A *Welcome DELL System Owner* screen will open; click **Next**.
8. A list of items with check marks next to them will appear.
9. Under *Modem Drivers* select **Conexant 56K v.9x DFVc Modem**.
10. Drag the scroll bar, do NOT use the mouse to scroll, down until you see the **Extract** button and then click on it.
11. Click **Continue**.
12. Click **OK**.
13. Click **Yes**.
14. Click **OK**.
15. When the Found New Hardware bubble says the hardware was installed, click on the **back button** in the upper left.
16. Under *Network (NIC) Drivers* select **Broadcom 44x 10/100 Integrated Controller**.
17. Drag the scroll bar down and click on the **Extract** button.
18. Click **Continue**.
19. Click **OK**.
20. Click **Yes**.
21. Click **OK**.
22. The device driver will install the Integrated Controller.
23. Click **Next**.
24. *Accept the license agreement* and click **Next**.
25. Click **Install**.
26. Click **Finish**.
27. Click the **back button**.
28. Under *Systems Drivers* select **ATI SMBus**.
29. Drag the scroll bar down and select **Extract**.
30. Click **Continue**.
31. Click **OK**.
32. Click **Yes**.
33. Click **OK**.
34. A wizard will pop up; click **Next**.
35. Click **Yes**.
36. Click **No, I will restart my computer later**.
37. Click **Finish**.
38. Click on the **back button**.
42. Scroll down and under *Audio Drivers* select **Analog Devices ADI 198x Integrated HD Audio**.
43. Drag the scroll bar down and click **Extract**.
44. Click **Continue**.

Reinstall DELL Drivers on DELL Premium PC

42. Click **OK**.
43. Click **Yes**.
44. Click **OK**.
45. A wizard will open after installing the hardware device.
46. Click **Next**.
47. Select **No, I will restart this computer later**.
48. Click **Finish**.
49. Click on the **back button**.
50. Under *Video Drivers* select **AMD Radeon HD 2400 Pro**.
51. Drag the scroll bar down and select **Extract**.
52. Click **Continue**.
53. Click **OK**.
54. Click **Yes**.
55. Click **OK**.
56. A window will open to install the utility for ATI Software.
57. Click **Next**.
58. Click **Yes**.
59. Select **Express**.
60. A pop-up may appear warning that you need to install .NET Framework. Click **OK**.
64. Wait a few seconds.
65. The ATI window will reappear and then disappear. A wizard will install.
66. Wait a few seconds.
67. Select **Yes, I want to restart my computer now** and click **Finish**. The PC will reboot.
68. Ensure the computer is plugged into an internet connection.
69. When the desktop appears click on **Start>All Programs>Activate Windows**.
70. A wizard will open.
71. Select **Yes, let's activate windows over the internet now**. Click **Next**.
72. Select **No, I don't want to register now, let's just activate Windows**. Click **Next**.
73. Click **OK**.
74. Right click anywhere on the desktop and select **Properties**.
75. Select the **Settings** tab.
76. In the resolution screen box move the selector to the far left and click **OK**. Click **Yes** on the pop-up.
77. Take out the DELL Drivers and Utilities disc.
78. Click on **Start**, put selector over My Computer, right click, and select **Properties**.
79. Click the **Advanced** tab.
80. Click the **Settings** button under *Startup and Recovery*.
81. Next to the *Time to display list of operating systems* change time from 30 seconds to 3 seconds.
82. Click **OK**.
83. Click **OK**.

You will need to install other programs (i.e. your shipping software, anti-virus, etc.) you may previously had installed from their respective CD's or websites. Also, ensure that Windows updates are current.