

## Reinstall DELL Drivers on DELL Premium PC

You received a Operating System disc and a Drivers & Utilities disc with your DELL PC.

1. Turn the computer on and when you get to the desktop insert *the DELL Drivers and Utilities* disc.
2. On the *Resource CD Installation* pop-up click **OK**.
3. A wizard will begin to install the CD.
4. Click **Next**.
5. Click **Install**.
6. Click **Finish**.
7. A *Welcome DELL System Owner* screen will open; click **Next**.
8. A list of items with check marks next to them will appear.
9. Under *Modem Drivers* select **Conexant 56K v.9x DFVc Modem**.
10. Drag the scroll bar, do NOT use the mouse to scroll, down until you see the **Extract** button and then click on it.
11. Click **Continue**.
12. Click **OK**.
13. Click **Yes**.
14. Click **OK**.
15. Click **OK**.
16. Click **OK**.
17. When the Found New Hardware bubble says the hardware was installed, click on the **back button** in the upper left.
18. Under *Network (NIC) Drivers* select **Intel 825xx Gigabit Platform LAN Network Device**.
19. Drag the scroll bar down and click on the **Extract** button.
20. Click **Continue**.
21. Click **OK**.
22. Click **Yes**.
23. Click **OK**.
24. The device driver will install.
25. Click the **back button**.
26. Under *Systems Drivers* select **Intel AMT HECI**.
27. Drag the scroll bar down and select **Extract**.
28. Click **Continue**.
29. Click **OK**.
30. Click **Yes**.
31. Click **OK**.
32. A wizard will pop up; click **Next**.
33. Click **Yes**.
34. Click **Next**.
35. Click **Next** after it finishes installing.
36. Click **Finish**.
37. Click on the **back button**.
38. Under *System Drivers* select **Intel AMT SOL/LMS**.
39. Drag the scroll bar down and select **Extract**.
40. Click **Continue**.
41. Click **OK**.

## Reinstall DELL Drivers on DELL Premium PC

42. Click **Yes**.
43. Click **OK**.
44. A wizard will open; click **Next**.
45. Click **Yes**.
46. Click **Next**.
47. On the *Intel Active Management Technology Status* window **check** the box *not to show the message again* and click **OK**.
48. Click **Next**.
49. Click **Finish**.
50. Click on the **back button**.
51. Under *System Drivers* select **Intel Chipset Software Installation Utility**.
52. Drag the scroll bar down and click **Extract**.
53. Click **Continue**.
54. Click **OK**.
55. Click **Yes**.
56. Click **OK**.
57. A wizard will pop-up; click **Next**.
58. Click **Yes**.
59. Click **Next**.
60. After the wizard finishes installing, click **Next**.
61. Select **No, I will restart this computer later** and Click **Finish**.
62. Click the **back button**.
63. Scroll down and under *Audio Drivers* select **Analog Devices ADI 198x Integrated HD Audio**.
64. Drag the scroll bar down and click **Extract**.
65. Click **Continue**.
66. Click **OK**.
67. Click **Yes**.
68. Click **OK**.
69. A wizard will open after installing the hardware device.
70. Click **Next**.
71. Select **No, I will restart this computer later**.
72. Click **Finish**.
73. Click on the **back button**.
74. Under *Video Drivers* select **AMD Radeon HD 2400 Pro**.
75. Drag the scroll bar down and select **Extract**.
76. Click **Continue**.
77. Click **OK**.
78. Click **Yes**.
79. Click **OK**.
80. A window will open displaying ATI Software.
81. After a few seconds a pop-up may appear warning that *You have chosen to install Catalyst Control Center. The minimum .NET Framework version required is 1.1. Please install before launching application.* Click **OK**.

## **Reinstall DELL Drivers on DELL Premium PC**

82. Wait a few seconds.
83. The ATI window will reappear and then disappear.
84. A wizard will install.
85. On the ATI Catalyst Control Center pop-up click **OK**.
86. Wait a few seconds.
87. Select **Yes, I want to restart my computer now** and click **Finish**.
88. The PC will reboot.
89. Ensure the computer is plugged into an internet connection.
90. When the desktop appears click on **Start>All Programs>Activate Windows**.
91. A wizard will open.
92. Select **Yes, let's activate windows over the internet now**. Click **Next**.
93. Select **No, I don't want to register now, let's just activate Windows**. Click **Next**.
94. Click **OK**.
95. Right click anywhere on the desktop and select **Properties**.
96. Select the **Settings** tab.
97. In the resolution screen box move the selector to the far left and click **OK**.
98. Click **Yes** on the pop-up.
99. Take out the DELL Drivers and Utilities disc.
100. Click on **Start**, put selector over My Computer, right click, and select **Properties**.
101. Click the **Advanced** tab.
102. Click the **Settings** button under *Startup and Recovery*.
103. Next to the *Time to display list of operating systems* change time from 30 seconds to 3 seconds.
104. Click **OK**.
105. Click **OK**.

*You will need to install other programs (i.e. your shipping software, anti-virus, etc.) you may previously had installed from their respective CD's or websites. Also, ensure that Windows updates are current.*